

Push the clips inward to ensure the luminaire can be installed into the mounting hole. Tighten the 2 screws to lower the fold-out tabs securing the luminaire into the ceiling. Replace the cover of the luminaire.




Do not cover luminaire or driver with thermally insulating material (A). It is recommended to allow a minimum of 50 mm clearance above the luminaire as shown in (B).



Restore power once installation has been completed.

Miniled XDV10 Recessed Downlight

Installation Guide







Miniled XDV10

trendlighting.com.au

For warranty information, please visit

trendlighting.com.au/warranty

Important Safety Information

Please read these installation instructions carefully before installing this luminaire.

- This product must be installed by a licensed electrician in accordance with AS/NZS 3000 and local regulations.
- Isolate the mains power supply prior to installation.
- Only reconnect mains power after installation is completed.
- No part of the luminaire should be altered or modified.
- This product is not user serviceable.

Approvals

The RCM marking of this product applies to AS/NZS 4417.1 "Regulatory compliance mark (RCM) for electrical and electronic equipment". This product is designed to conform to AS/NZS 60598 "Luminaires, general requirements and tests".





















Mark at the correct location. Cut a hole in the ceiling in accordance with cutout size. XDV10 ceiling cutout: **125 mm**



To maintain IP65 rating on XDV10, ensure that the luminaire is installed on a flat level ceiling and that the luminaire has an adequate seal to the mounting surface.





Miniled XDV10 Installation Guide Trend Lighting Co. Pty Ltd trendlighting.com.au