

We recommend removing insulation sitting directly on top of the luminaire to ensure optimal performance. However, this is not mandatory as the luminaire meets or exceeds the requirements for IC-4 when covered. Do not cover the driver.






V1-01.04.2023 Product designs and technical data may be subject to change

## Resiled RDF8 Recessed Downlight

Installation Guide







**Trend Lighting Co. Pty Ltd** 

## For warranty information, please visit

trendlighting.com.au/warranty


## **Important Safety Information**

Please read these installation instructions carefully before installing this luminaire.


- This product must be installed by a licensed electrician in accordance with AS/NZS 3000 and local regulations.
- Isolate the mains power supply prior to installation.
- Only reconnect mains power after installation is completed.
- No part of the luminaire should be altered or modified.
- This product is not user serviceable.

## **Approvals**


The Resiled range is IC-4 rated and can be installed in locations where it is covered or abutted with thermally insulating material in accordance with AS/NZS 60598.2.2:2016.




The RCM marking of this product applies to AS/NZS 4417.1 "Regulatory compliance mark (RCM) for electrical and electronic equipment". This product is designed to conform to AS/NZS 60598 "Luminaires, general requirements and tests".




Mark at the correct location. Cut a hole in the ceiling in accordance with cutout size. RDF8 ceiling cutout: **76-92 mm** 



To maintain IP65 rating on RDF8, ensure that the luminaire is installed on a flat, level ceiling and that the luminaire has an adequate seal to the mounting surface.





Resiled RDF8 Installation Guide Trend Lighting Co. Pty Ltd trendlighting.com.au